


CLIP CHECKER 64PIN DETAILS



PIN NO	PURPOSE
1,5,9,13,17,21,25,29,33,37,41,45	NOT USED
2,6,10,14,18,22,26,30,34,38,42,46	LED INDICATION O/P
3,7,11,15,19,23,27,31,35,39,43,47 4,8,12,16,20,24,28,32,36,40,44,48	I/O FOR CLIP PRESENCE
49-64	DUMMY

MODULE 4 PIN CONNECTION

